

HEAT MOLDING INSTRUCTIONS

This boot is equipped with the next generation heat moldable thermoplastics built into the boot. This boot is suitable for heat molding in your oven. Pre heat your oven to 85°C or 185°F. Remove all bolts, frames, blades, laces etc from the boot. Place the boots in the oven for 20-30 minutes. Higher temperatures may damage your boots. Caution: Do not place your feet in hot boots or you may burn your feet. Let them cool a little first. Test the boot temperature with your hand before placing your foot inside. Mount the frame/blade to the boot and stand in it.

Tighten the boot with laces (and buckle) and wait until the boot cools. Or use the plastic end of a screwdriver to push out any area causing discomfort. You can heat mold your boot as many times as you like. Custom Boots: Your custom boots may initially feel too small. They will need a few weeks to break in. Make sure your foot is all the way in the back of the boot and heat mold them if necessary.